

Garden Kneeler Instruction Manual

G0999

Safety

- Max user weight limit: 100kgs
- This product has been designed for careful domestic indoor or outdoor use.
- To prevent accidents, do not put your hands or fingers near the springs either when using or when folding/unfolding.
- Open out onto a flat surface, never on a slope.
- To avoid tip-over, do not throw your weight on to the kneeler.
- Do not allow children to play on or around the kneeler
- Only one person should use the kneeler at any one time.

Contents

- 1 x Garden Kneeler
- 1 x Instruction Manual
- 1 x Tool holder

How to use

- **To unfold:** Place the kneeler on a flat surface and simply unfold each foot until they click in to place.
- **To fold:** CAREFULLY (to avoid catching your fingers or hand in the springs) push the metal bar towards the foot with one hand and fold the foot down with the other.

Cleaning and maintenance

- The frame and fabric of the kneeler can be cleaned with a soft cloth using warm soapy water.
- When not in use store in a cool, dry place





**GUARANTEE
IMPORTANT**

**Please do not return this product without first calling the Customer Service number below:
0871 911 7031**

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service:

Customer Service Department, Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP, UK

Telephone: 0871 911 7031

E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.

Colours and contents may vary.

*Calls cost 13p per minute plus your phone company's access charge

AFTER SALES SUPPORT ☎ 0871 911 7031 💻 CUSTOMERSERVICE@GARDENGEARONLINE.CO.UK